



CAROMA

# COOLIBAH CONTEMPORARY LEVER - BATH OUTLET

## PLUMBERS INSTALLATION INSTRUCTIONS

### Important Information

\* All pipework must be thoroughly flushed prior to installation.

### Installation

- 1) Check that threaded nipple (1) is the correct length, as shown. Apply thread tape to the thread.
- 2) Screw the bath outlet (2) onto the threaded nipple (1) and position as required. DO NOT OVERTIGHTEN.

### Removing Aerator Insert

- 1) Carefully remove aerator housing (3) from bath outlet (2), taking care not to damage the decorative finish.
- 2) Remove 'O'Ring (5) & aerator insert (4) from aerator housing (3). Check that aerator housing (3) is clean. Deposits of lime can be removed by washing in a vinegar solution.
- 3) Fit aerator insert (4) into aerator housing (3) followed by 'O'Ring (5) then screw assembly into bath outlet (2) and tighten securely (to prevent removal by hand).

### IMPORTANT

#### Pressure & Temperature Requirements.

- Hot and cold water inlet pressures should be equal.
- Static inlet pressure range : 150 -1000 kPa  
New Regulation :-500 kPa maximum operating pressure at any outlet within a building. (Ref. AS/NZS 3500.1)
- Maximum hot water temperature : 80°C.

