



VIRIDIAN - WALL MIXER WITH WALL BATH OUTLET & PLATE (RH/LH)

PLUMBERS INSTALLATION INSTRUCTIONS

Important Information

- * In-wall components must be mounted accurately to ensure tapware operates correctly when installed.
- * Brazed connections should NOT be made directly onto the mixer, as excessive heat will cause permanent damage.
- * All pipework must be thoroughly flushed prior to installation.

Installation

- 1) Fit mixer body (8) onto a suitable mounting plate or noggin in the wall and secure using screws through the holes in its base. When facing the mixer, the connections should be as follows :
Hot water inlet connection 'H' to the left.
Cold water inlet connection 'C' to the right.
Mixed water outlet connection, vertically upwards.
Note : A suitable elbow fitting (11⁺) should be fitted to the inlet connection adjacent to the bath outlet (18) (Fig.2).
Check all connections for leaks.
Important :
* Mixer body (8) must be installed square to wall/tile face, to ensure cover plate (10) sits flush.
* To avoid damaging the decorative finish, do not remove the plastic protective sleeve until installation has been completed.
- 2) Accurately mount a wall elbow (12⁺) (or equivalent) for connection to the bath outlet in the desired orientation (to the right or left of mixer body)(Fig. 3).
Important :
All care should be taken that the wall elbow (12⁺) is mounted accurately in line with, and at a distance of 90mm±2 from the adjacent mixer body (8) and that it is square to the wall/tile face (Fig.2). Connect the mixer body outlet to the wall elbow (12⁺). **Note**: Pipework and fittings are not supplied.
- 3) Ensure that the trim cover (9) is fitted to the cover plate (10) to suit RH or LH installation (Fig 3). Apply a suitable clear sealant to the back face of the cover plate (10) to prevent water from entering the wall cavity, leaving an unsealed section at the bottom for drainage (Fig. 1).
Carefully slide the cover plate (10) together with trim cover (9) onto the mixer body (8), push firmly on the trim cover until cover plate (10) contacts the wall/tile face & sealant has formed a waterproof joint. Wipe clean any excess sealant from the chrome surfaces & the wall/tile face (See Fig. 1).

IMPORTANT
<u>Pressure & Temperature Requirements.</u>
<ul style="list-style-type: none"> • Hot and cold water inlet pressures should be equal. • Static Inlet pressure range : 150 -1000 kPa New Regulation :-500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1-2003, Clause 3.3.4) • Maximum hot water temperature : 80°C.
<u>Installation Requirements.</u>
<ul style="list-style-type: none"> • The installing plumber is responsible for waterproofing all penetrations for Taps in Shower areas at installation by a proprietary flange system or a sealant. (Ref AS3740-2010, Clause 3.10)

- 4) Fit handle (1) as shown, taking care that it is pushed fully down, then tighten grub screw (2) using 2.5mm allen key (3). Insert plug (4) taking care not to damage the decorative finish.
- 5) Apply thread tape to the thread of wall elbow (12⁺).
Important: Care must be taken that thread tape cannot become dislodged and block the flow regulating device, causing a reduction in water flow.
Screw the adaptor (13) onto the threaded wall elbow (12⁺), using a 10mm allen key (15⁺), until the cover plate (10) is held securely against the wall/tile face. **DO NOT OVERTIGHTEN**.
Apply suitable lubricant to 'O'Rings (14) on adaptor (13).
- 6) Fit bath outlet (17) onto spigot of adaptor (13), then push it firmly against the cover plate while tightening grub screws (16) using the 2.50mm allen key (3) provided. Take care that the top face of the bath outlet is horizontal before tightening screws (16).
- 7) Turn on Hot and Cold water supplies and check operation.

Replacing Cartridge (Fig. 1)

- 1) Turn off hot and cold water supplies.
- 2) Carefully remove plug (4) before using a 2.5mm allen key (3) to loosen grub screw (2) and remove handle (1). Remove cap (5) taking care not to damage the decorative finish. Unscrew nut (6) then lift out old cartridge (7).
- 3) Ensure inside face of mixer body (8) is clean. Check that seal is in position in base of new cartridge (7). Fit new cartridge (7) into mixer body (8), taking care that two lugs on base of cartridge (7) fit into mating holes in mixer body (8).
- 4) Screw on nut (6). **Important**:- Nut (6) should be tightened to a torque of 10 Nm.
- 5) Replace cap (5), tightening by hand. Fit handle (1) taking care that it is pushed fully down, then tighten grub screw (2).
Replace plug (4) taking care no to damage the decorative finish.
- 6) Turn on water supplies and check operation.

+ Not supplied.



VIRIDIAN - WALL MIXER WITH WALL BATH OUTLET & PLATE (RH/LH)

+ Not supplied.

PLUMBERS INSTALLATION INSTRUCTIONS

