



ENIGMA - BATH OUTLET

+

PLUMBERS INSTALLATION INSTRUCTIONS

Important Information

* All pipework must be thoroughly flushed prior to installation.

Installation (Fig.1)

- 1) Check that threaded nipple (2) is the correct length, as shown. Cut to length if required ensuring end face is square. Apply thread tape to the thread.
- 2) If required, place the optional 'square cover plate (1), over the threaded nipple (2). Screw the base (4) together with seal (3) onto the threaded nipple (2), using a 6mm allen key (5+) (not supplied), until the seal (3) contacts the wall/tile face (or the cover plate (1) if fitted). DO NOT OVERTIGHTEN. Apply suitable lubricant to the 'O'Rings on base (4).
- 3) Fit wall outlet (7) onto spigot of base (4), then push it firmly against the base while tightening grub screws (8) using the 2.0mm allen key (6) provided. Take care that the top face of the wall outlet (7) is horizontal before tightening screws (8).
- 4) Turn on Hot and Cold water supplies and check operation.




Fig. 1

IMPORTANT	
<u>Pressure & Temperature Requirements.</u>	
•	Hot and cold water inlet pressures should be equal.
•	Static Inlet pressure range : 150 -1000 kPa New Regulation:- 500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1)
•	Maximum hot water temperature : 80°C.

+ Not supplied.

+