



VIRIDIAN - BATH OUTLET

+

Important Information

* All pipework must be thoroughly flushed prior to installation.

Installation

- 1) Check that threaded nipple (1) is the correct length, as shown. Apply thread tape to the thread. Slide cover plate (2) onto threaded nipple (1). Screw adaptor (3) onto threaded nipple (1) using a 10mm allen key (5⁺) until cover plate (2) is held securely against wall/tile face and the 'Dorf' marking is at the bottom, as shown in Fig. 2. DO NOT OVERTIGHTEN. Apply suitable lubricant to 'O'Rings (4) on adaptor (3).
- 2) Fit the bath outlet (6) onto spigot of adaptor (3), then push it firmly against the wall cover plate (2) while tightening grub screws (7) using the 2.50mm allen key (8) provided. Take care that the top face of the bath outlet is horizontal before tightening screws (7).

IMPORTANT
Pressure & Temperature Requirements.
• Hot and cold water inlet pressures should be equal.
• Static Inlet pressure range : 150 -1000 kPa New Regulation :-500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1-2003, Clause 3.3.4)
• Maximum hot water temperature : 80°C.

+ Not supplied.




Fig. 1




Fig. 2