



VILLA - BATH OUTLET

+

PLUMBERS INSTALLATION INSTRUCTIONS

Important Information

- * All pipework must be thoroughly flushed prior to installation.

Installation (Fig.1)

- 1) Check that threaded nipple (2) is the correct length, as shown. Cut to length if required ensuring end face is square. Apply thread sealant to the thread.
- 2) Select the desired cover plate (5) (round or square shape) and attach the plate (with the dorf marking aligned horizontally at the bottom) to the outlet (8), using screws (4). Screw the spigot (2) onto the threaded nipple (1) to provide a watertight connection. Apply suitable lubricant to 'O'Rings (3).
- 3) Fit wall outlet (8) together with cover plate (5) onto the spigot (2), then carefully push it firmly against the wall/tile face while tightening grub screws (6) using the 2.5mm allen key (7) provided. Take care that the cover plate is aligned with the tiles and the aerator (9) is pointing vertically downwards before tightening screws (6).
- 4) Turn on Hot and Cold water supplies and check operation.

IMPORTANT

Pressure & Temperature Requirements.

- Hot and cold water inlet pressures should be equal.
- Static Inlet pressure range : 150 -1000 kPa
New Regulation:- 500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1)
- Maximum hot water temperature : 80°C.




Fig. 1

+